

# X/WING

tail tidy

## 1 before you get started.

Grab your tools, you'll need them.  
\*1/8" allen wrench for preassembly

1 CURVED PLATEHOLDER  
1 MOUNTING BRACKET  
ASSEMBLY HARDWARE (2) 1/4"-20 SCREWS

LICENSE PLATE SCREWS AND NUTS (4 EA)

## 2 preassemble

Lay out the bracket and the plateholder in front of you, like so >>



Using the two 1/4"-20 screws, assemble the mounting bracket and hardware in the orientation shown below. The tail tidy is now ready attach to the bike's subframe.



COMBUSTION  INDUSTRIES