

X/WING

tail tidy

1 before you get started.

Grab your tools, you'll need them.

- *8mm allen wrench to remove the fender
- *putty knife or screwdriver to remove plastic plugs
- *3mm allen wrench (to remove the hardware that holds the stalk to the bottom of the subframe)

2 preassemble

Lay out the bracket and the plateholder in front of you, like so >>



1 CURVED PLATEHOLDER
1 MOUNTING BRACKET
ASSEMBLY HARDWARE (2) 1/4"-20 SCREWS

LICENSE PLATE SCREWS AND NUTS (4 EA)

Using the two 1/4"-20 screws, assemble the mounting bracket and hardware in the orientation shown below. The tail tidy is now ready attach to the bike's subframe.



COMBUSTION INDUSTRIES