


Dual function signal install - FTR

front use only (amber turn/white running light)



polarity converter;
custom dynamics

<https://www.customdynamics.com/universal-turn-signal-polarity-converter>



df.trn_amb_sct